

Monoxivent XL Hose Reel Programming Setup

1. Step 1

Connect one end of the Communication Cord to the Lift Master Pendulum as shown below.



MONOXIVENT[®]

Source Capture Systems

2. Step 2

Connect the other end of the Communication Cord to the Wall Control terminals of the Lift Master motor inside of the XL Hose Reel Housing as shown below. Observation of polarity is not required.



1306 Mill St., Rock Island, IL 61201
PH 309-794-1000, FX 309-794-1020

www.monoxivent.com

Eliminate Toxic Fumes with Monoxivent!

3. Step 3

Select Door Type: **Rolling Door and Save/Enter.**



4. Step 4

Select Door Settings: **Insulated Door and Save/Enter.**



MONOXIVENT[®]

Source Capture Systems

5. Step 5

Select Door Height: Set this height to the length of hose you have ordered for the XL Hose Reel and **Save/Enter**.



1306 Mill St., Rock Island, IL 61201
PH 309-794-1000, FX 309-794-1020

www.monoxivent.com

Eliminate Toxic Fumes with Monoxivent!

MONOXIVENT[®]

Source Capture Systems

6. Step 6

Select Width: Set this width to the width of drum that you have ordered for the XL Hose Reel and **Save/Enter**.



1306 Mill St., Rock Island, IL 61201
PH 309-794-1000, FX 309-794-1020

www.monoxivent.com

Eliminate Toxic Fumes with Monoxivent!

MONOXIVENT[®]

Source Capture Systems

7. Step 7

Select Sprocket. **72 Tooth and Save/Enter.**



8. Step 8

Select Open Limit: **Press and hold the up button** until the hose is all the way up or as high as you want it to be **and Save/Enter.**

9. Step 9

Select Closed Limit: **Press and hold the down button** until the hose is all the way down or as far down as you want it to be **and Save/Enter.**

Set up is now Complete. If you require additional assistance, please see the enclosed Lift Master instruction manual.

1306 Mill St., Rock Island, IL 61201
PH 309-794-1000, FX 309-794-1020

www.monoxivent.com

Eliminate Toxic Fumes with Monoxivent!